

Quality Assurance Department
Marktec Corporation
17-35, Omori Nishi 4-chome
Ota-ku
Tokyo 143-0015
Japan
Tel: +81-3-3762-4453

Dear Customer,

USING THE SUPER-LIGHT D-10B and D-10C

Thank you for purchasing a Marktec Super-Light D-10B or D-10C. We ask you to note the following points on the use of these products.

1. Waiting six minutes before switching the lamp on again

When the lamp has just been switched off, the vacuum tube is hot and the pressure of the metallic vapor inside it is high. The lamp cannot readily come on again in this condition. It needs about six minutes to cool sufficiently for its next discharge. Please wait at least six minutes before you switch on the power again. If you switch on the power again without waiting at least six minutes, the vacuum tube could deteriorate and the stabilizer could fail. If the lamp needs more than six minutes to come on again, please contact Marktec as the vacuum tube may have deteriorated.

2. Caution indication on stabilizer case

To help ensure that your lamp gives long service, the upper part the power switch on the stabilizer case carries a caution label about switching the lamp on again. We affix the same kind of label to the power switch of any lamp that we repair. We also offer caution labels that you can affix yourself. If you would like us to supply them, please let our sales staff know how many you need.

We constantly strive to improve the quality of our products and service. We appreciate your custom, and we look forward to continuing to serve you.

MARKTEC Corporation
NARITA PLANT Q. A. Department.


